

## INSTALLING A KEEL LIST (70047 or 70048)

1. Cover the surface around the keel. Clean the keel's surface and dry it properly. (Picture 1).

2. Drill holes through the keel list appr. every 50cm (Picture 2) however more densely in the bow where the list is bent. (Picture 3). Use a larger drill to widen the hole in order to create space for the screwheads (later covered with Terhi Fix).

3. Spread Fix on the keel and the keel list with a spatula. (Picture 4). Press then the keel list firmly against the keel.

4. Install the screws starting from the bow. Beware of overtightening the screws (Picture 5).

5. Even the edges with a spatula so the area is easy to sand after Fix has dried. Spread Fix also into screwholes. (Picture 6)

6. Let dry for 24 h, sand excessive Fix off and paint over. Light tones of antifouling are recommended.

### Materials:

70047 / 70048 keel list 5m/3m 1 pc  
72104 FIX 300 g 1 pc  
Screws as many as needed (stainless steel A4 tapping screws).  
Antifouling paint

**NB. The surfaces must be dry and clean.  
The temperature should be least +15  
degrees during the whole drying period of  
24 h.**

